

## FM-750 Display: Hard and Soft Reset

This support bulletin describes the correct procedures for performing a hard and soft reset on the Trimble® FM-750™ display.

### Hard reset

When you perform a hard reset, all settings return to the factory defaults. This deletes all saved data, including any field data. To do this:

1. Power down the display and then power it on.
2. Wait until the status bar at the bottom of the second startup screen is over three quarters full:



3. Press the power button and **both** brightness control buttons at the same time:



4. Hold the buttons down until the display beeps (about 30 seconds).

### Soft reset

When you perform a soft reset, all settings return to the factory defaults. All saved field data remains intact. To do this:

1. Power down the display and then power it on.
2. Wait until the status bar at the bottom of the second startup screen is over three quarters full:



3. Press the power button and the top one of the two brightness buttons at the same time:



4. Hold the buttons down until the display beeps (about 30 seconds).

This document is for informational purposes only and is not a legally binding agreement or offer. Trimble makes no warranties and assumes no obligations or liabilities hereunder.